920-544

Carrier VoIP Integrated Element Mgmt System (IEMS) Ops

DEMO

QUESTION NO: 1

Which feature is part of the alarm count panel?

A. Alarms with a warning severity are not shown.
B. A summary of all critical alarms may be obtained.
C. An annotation may be made from the alarms count panel.
D. Alarms may be acknowledged from the alarms counts panel.

Answer: B

QUESTION NO: 2

Under which of the following in the topology tree is the Alarms node found?

A. Inventory
B. Performance
C. Network Events
D. Fault Management

Answer: D

QUESTION NO: 3

Which action may be used to display the icon of the managed object that is the source of a given

alarm?

A. From the alarm popup menu, select Show Map.
B. Double-click onthe alarm and select Show Map Detail.
C. From the alarm popup menu, select Show Managed Object.
D. Double-click onthe alarm and select Managed Object Detail.

Answer: A

QUESTION NO: 4

Which of the following is true for events that are received from devices that are not part of

Integrated EMS inventory database?

A. The IEMS will temporarily add the source device to the inventory.

B. These events have a source field value of Unrecognized Device.

C. The IEMS application assigns these events a logkey value of IEMS601.

D. The IEMS application will propagate these events to alarms with a minor severity.

Answer: C

QUESTION NO: 5

Which protocol is used to establish an Operator Client session from the IEMS into the Multiservice Data Manager?

A. SSH

B. Telnet

C. HTTPS

D. SNMPv3

Answer: C

QUESTION NO: 6

Which Network Element requires its GUI element manager application to be installed on the client?

A. STORM

B. Call Agent

C. ERS 8600

D. MSS 15000

Answer: C

QUESTION NO: 7

Which statement is true for performing IEMS application upgrades in a dual server (HA) environment?

A. During the upgrade, neither server is in service.

B. The upgrade must first be performed on the active server.

C. A failover must not be performed until both servers are upgraded.

D. Upgrades are performed on the standby server, while the active server is in service.

Answer: D

QUESTION NO: 8

How many simultaneous sessions of each of the four supported Northbound fault streams are

supported?

A. 2
B. 4
C. 6
D. 8

Answer: C

QUESTION NO: 9

Which two must be provisioned on the IEMS in order to set up a Northbound SNMP fault stream?
(Choose two.)

A. the directory of the SNMP trap destination host (Managerdir)
B. the MAC address of the SNMP trap destination (Managermac)
C. the IP address of the SNMP trap destination host (Managerhost)
D. the port number of the SNMP trap destination host (Managerport)

Answer: C,D

QUESTION NO: 10

Which Servman command can be issued to start the IEMS server application?

A. start IEMS
B. servstart IEMS
C. startserv IEMS
D. servman start IEMS

Answer: B

QUESTION NO: 11

Which steps from the IEMS menu are required to launch the alert filter configuration tool?